

# Product leaflet

**Product**  
Bump cap

**Model No.**  
T06-0602

**Ordering No.**  
T06-0602

## Product description

A bump cap may be worn where the user risks knocking their head on a hard, sharp or protruding object, for instance in confined spaces. A bump cap is not a safety helmet and, for this reason, should not be used to protect against falling or moving objects.

The T06-0602 bump cap is designed to be used with the Sundström SR 570 Loose fitting face shield. The user can fit the bump cap easily to the SR 570, such that the complete product provides head protection for the user. The product protects the user's head if it collides with stationary objects.


The bump cap can be used with the SR 570 Loose fitting face shield in all the configurations the face shield is approved for.

## Technical specification

T06-0602

<b>Material</b>	PC/ABS
<b>Service temperature</b>	-10 – +55°C, < 90 % RH
<b>Storage temperature</b>	-20 – +40°C, < 90 % RH
<b>Weight, SR 570 with Bump cap</b>	≈ 940 g

- A. SR 570
- B. Bump cap



**Sundstrom Safety Inc.**

143 Maple St.  
Warwick, RI 02888

Office: 1-401-434-7300  
Toll Free: 1-877-SUNDSTROM  
Fax: 1-401-434-8300

info@srsafety.com  
www.srsafety.com