



Spare parts / Accessories



No.	Description	Ordering No.
1.	Helmet, incl. air duct	R06-0830
2.	Leaf spring with screw	R06-0806
2a.	Leaf spring	-
2b.	Screw	-
3.	Upper frame set	R06-0802
3a.	Upper frame	-
3b.	Screw	-
4.	Visor, PC	R06-0808
5.	Lower frame set	R06-0803
6.	Set of valves	R06-0807
6a.	Membrane	-
6b.	Cover exhalation valve	-
7.	Face seal	R06-0805
8.	Head harness	R06-0804
9.	Sweatband	R06-0809
10.	Neck comfort band	T06-0803
11.	Gasket	R01-1205
12.	Breathing hose	R06-0810
13.	O-ring	R06-0202
14.	Peel of set SR 582	T06-0801
15.	Cleaning wipes. 50/box	H09-0401
16.	Frame, welding shield	R06-0816
17.	Adapter R+L 17a. Adapter R x1 17b. Adapter L x1 17c. Screw x4	R06-0820
18.	Knob complete Knob x2 Washer x2	R06-0821
19.	Lock device complete 4a. Lock device 4b. Spring	R06-0819
20.	Welding filter, shade No. 8, SR 59008	T06-4001
	Welding filter, shade No. 9, SR 59009	T06-4002
	Welding filter, shade No. 10, SR 59010	T06-4003
	Welding filter, shade No. 11, SR 59011	T06-4004
	Welding filter, shade No. 12, SR 59012	T06-4005
	Welding filter, shade No. 13, SR 59013	T06-4006

No.	Description	Ordering No.
21.	Correction lens, dptr 1.0, SR 59014	T06-4010
	Correction lens, dptr 1.5, SR 59015	T06-4011
	Correction lens, dptr 2.0, SR 59016	T06-4012
	Correction lens, dptr 2.5, SR 59017	T06-4013
22.	Inner protective lens for automatic filter	R06-4009
23.	Welding filter EN 3/10 SR 59005	T06-4007
	Welding filter EN 3/11 SR 59006	T06-4008
	Welding filter EN 4/9-13 SR 59007	T06-4009
24.	Spring for welding filter	R06-0818
25.	Protective lens PC	R06-4008
26.	Holder protective lens	R06-0817
27.	Face seal	T06-8012
28.	Neck and chest protection	T06-8011
29.	Protective hood, SR 59018	T06-4014
30.	Protective hose for the breathing hose	T06-4016